




**ES51.2-400BS**  
**Energy Storage LiFePO<sub>4</sub> Battery**  
**User Manual**

**MADE IN INDIA**

# Connection Diagram



# Important safety instructions



## Important safety instructions

Please keep this manual for future reference.

This manual contains all the safety installation and operation instructions of the rack type energy storage LiFePO<sub>4</sub> battery.

Please read all instructions and precautions in the manual carefully before installation and use.

1. To avoid personal injury, users should disassemble it by professional installer.  
If need repairs, please contact our company's professional maintenance personnel.
2. Do not install the energy storage LiFePO<sub>4</sub> battery in a place where children can touch.
3. Do not install the energy storage LiFePO<sub>4</sub> battery in harsh environments such as damp greasy, flammable, explosive, or dust accumulation.
4. When the energy storage LiFePO<sub>4</sub> battery is working, please do not open the box.
5. It is recommended to install a suitable fuse or circuit breaker externally.
6. After installation, check whether all line connections are tight to avoid the risk of heat accumulation due to virtual connection.
7. Rack energy storage battery shall be charged with solar power or AC power supply, parallel connection with other AC power supply or different voltage and brand batteries is prohibited.

# Contents



|  |       |
|--|-------|
| <b>1. Safety Precautions</b>                                   | 3~4   |
| 1.1 Before Connecting  | 4     |
| 1.2 In Using   | 4     |
| <b>2. Basic information</b>                                    | 5~7   |
| 2.1 Product overview   | 5     |
| 2.2 Features   | 5     |
| 2.3 Function description                                       | 6     |
| 2.4 One battery module   | 6     |
| 2.5 Cabinet details  | 7     |
| <b>3. Installation process</b>                                 | 8~11  |
| 3.1 Installation Steps   | 8     |
| 3.2 Installation notes   | 9     |
| 3.3 Installation and connection                                | 9~10  |
| 3.4 Recommended external wiring diameter and switch selection. | 10    |
| 3.5 Necessary Installation Tools                               | 11    |
| 3.6 Personal Protective Equipment +1000 Vdc Insulated Tools    | 11    |
| <b>4. Parallel structure diagram</b>                           | 12~14 |
| 4.1 Recommended setting data of inverter                       | 14    |
| <b>5. LED instructions</b>                                     | 15~16 |
| <b>6. BMS communication settings</b>                           | 17~21 |
| 6.1 BMS communication and setting                              | 17    |
| 6.2 Communication Instructions                                 | 18    |
| 6.3 Inverter Compatibility List                                | 19    |
| 6.4 Low Voltage Battery to inverter CAN Terminal Pin Out       | 20    |
| 6.5 Low Voltage Battery to inverter RS485 Terminal Pin Out     | 21    |
| <b>7. Technical parameter list</b>                             | 22    |
| <b>8. Maintenance and conservation</b>                         | 23    |
| <b>9. Warranty record card</b>                                 | 24    |

## 1. Safety Precautions



### Reminding!

- (1) It is important and necessary to read the user manual carefully before installing or using battery. Failure to do so or to follow any of the instructions or warnings in this document can result in electrical shock, serious injury, or death, or can damage battery, potentially rendering it inoperable.
- (2) If the battery is stored for longtime, it is required to charge every six months.
- (3) Battery needs to be recharged within 12 hours after fully discharged.
- (4) Do not install the product in outdoor environment, or an environment out of the operation temperature or humidity range listed in manual.
- (5) Do not expose cable outside.
- (6) Do not connect power terminal reversely.
- (7) All the power terminals must be disconnected for maintenance.
- (8) Please contact the supplier within 24 hours if there is something abnormal.
- (9) Do not use cleaning solvents to clean battery.
- (10) Do not expose battery to flammable or harsh chemicals or vapors.
- (11) Do not paint any part of battery, include any internal or external components.
- (12) Do not connect battery with PV solar wiring directly.
- (13) Any foreign object is prohibited to insert into any part of battery.
- (14) The warranty claims are excluded for direct or indirect damage due to items above.



## 1.1 Before Connecting



### Warning! ! !

- (1) After unpacking, please check product and packing list first, if product is damaged or lack of parts, please contact with the local retailer.
- (2) Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode.
- (3) Wiring must be correct, do not mistake the positive and negative cables, and ensure no short circuit with the external device.
- (4) It is prohibited to connect the battery and AC power directly.
- (5) Please ensured the electrical parameters of battery system are compatible to related equipment.
- (6) Keep the battery away from water and fire.

## 1.2 In Using

- (1) If the battery system needs to be moved or repaired, the power must be cut off and the battery is completely shutdown.
- (2) It is prohibited to connect the battery with different type of battery.
- (3) It is prohibited to connect batteries with faulty or incompatible inverter.
- (4) It is prohibited to disassemble the battery (QC tab removed or damaged).
- (5) In case of fire, dry powder fire extinguisher or vast amount of water can be used.
- (6) Please do not open, repair or disassemble the battery except professional installer.

We do not undertake any consequences or related responsibility which because of violation of safety operation or violating of design, production and equipment safety standards.

## 2. Basic information

### 2.1 Product overview

Rack type energy storage battery is mainly used in the field of household power storage. At the same time, it is also suitable for the internal energy storage of RV, household energy storage and temporary buildings. It adopts high-performance and long-life lithium iron phosphate battery as the basic energy storage unit, combined with advanced lithium-ion battery management system industrial design of household products and other technologies. Ensure that products have high reliability and high industrialization standards.


Rack type products can support external parallel use function, which greatly improves the convenience of use. Through scientific and reasonable active heat dissipation. Rack type energy storage battery improves the consistency of internal temperature field, prolongs service life, and enables the product to continuously output high current.

### 2.2 Features


- ◆ The battery adopts high-performance lithium iron phosphate battery with high safety performance and long service life.
- ◆ External weak current switch reduces product power consumption and improves the safety of transportation and storage.
- ◆ With RS485/CAN communication function, it can easily communicate with the equipment with communication.
- ◆ It has multiple protection functions to protect the safety of power supply in an all-round way.
- ◆ The output is stable and can be connected to different loads within the voltage range.
- ◆ Support up to 3 groups of ES51.2-400BS used in parallel.

## 2.3 Function description


ES51.2-400BS is composed of 4 battery modules and a cabinet, as shown below.



### 2.4 One battery module




|    |                     |    |                              |
|----|---------------------|----|------------------------------|
| 1  | Switch              | 5  | Welding parts of upper cover |
| 2  | Panel               | 6  | Box                          |
| 3  | Red terminal        | 7  | Box fixings                  |
| 4  | Black terminal      | 8  | Box handle                   |
| 9  | Reset               | 12 | RS485 communication          |
| 10 | RS485 communication | 13 | CAN communication            |
| 11 | RS485 communication | 14 | LED indicator                |




|   |                    |   |                     |
|---|--------------------|---|---------------------|
| 1 | Main Frame Pillars | 5 | Caster wheels       |
| 2 | Side cover         | 6 | Main body top cover |
| 3 | Partition          | 7 | Cabinet front door  |
| 4 | Bottom plate       | / | /                   |

3.1 Installation Steps

Install a battery module to the bottom layer of the battery cabinet, and then continue installation from bottom to top in the same way



After the battery module is installed, connect the power cable and communication cable in turn, as shown in the figure below:




### 3.2 Installation notes

Before installation, please read this manual carefully and familiarize the installation steps.

- (1) Be sure to leave a certain space around for heat dissipation during installation.
- (2) Avoid sunlight direct and rainwater infiltration during outdoor installation to cause battery damage.
- (3) Do not place metal products near the place of the energy storage LiFePO<sub>4</sub> battery installation to prevent short circuits.
- (4) Virtual connection points and corroded wires may generate high heat, and the molten insulation layer will burn surrounding materials and even cause a fire. Therefore, it must be ensured that the connector has been tightened and the wires should be secured with cable ties to avoid loosening of the connector due to shaking during mobile applications.
- (5) After the battery switch is turned off, there is still high voltage inside the energy storage case. Please do not open or touch the internal components, and external short circuit is strictly prohibited.
- (6) Please do not install it in a harsh environment where a large amount of damp, greasy, flammable and explosive dust gathers.
- (7) It is forbidden to reverse the charging and discharging terminals of the battery, otherwise it is very easy to damage the battery or cause unpredictable risks.
- (8) If an injury occurs during installation or use, please seek medical attention in time.

### 3.3 Installation and connection

Installation and connection must comply with national and local electrical code requirements. According to the current situation, firstly, choose the corresponding wire or a wire with a larger wire diameter to avoid unnecessary troubles during use. Secondly, determine the installation location. Thirdly, when installing, please make sure to leave at least 200 mm of space at the air outlets on both sides of the energy storage battery to ensure natural convection heat dissipation.



### 3.4 Recommended external wiring diameter and switch selection.

| Model        | Recommended external wiring diameter | Battery continuous current circuit breaker | Circuit breaker Model |
|--------------|--------------------------------------|--|-----------------------|
| ES51.2-400BS | 25mm <sup>2</sup> /4AWG              | 100A                                       | 2P-125A               |

Note: The wiring diameter is for reference only. If the distance between the load and the battery is relatively long, use a larger wire to reduce the voltage and improve the system performance. The above wiring diameter and circuit breaker are only recommendations, please follow the actual choose the appropriate wire diameter and circuit breaker according to the situation.

### 3.5 Necessary Installation Tools



|   |  |   |  |
|---|--|---|--|
|  <p>Multimeter + Current clamp</p> |  <p>Insulated Screwdriver Set</p>   |  <p>Insulated Allen Key Set from 2 mm to 8 mm</p> |  <p>Drill+Hammer</p>                          |
|  <p>Electrician Scissors</p>       |  <p>Insulated Torque Wrench Set</p> |  <p>Lifting Strap + Mechanical Lifter</p>         |  <p>RS232/USB +Screw Terminal (insulated)</p> |



### 3.6 Personal Protective Equipment +1000 Vdc Insulated Tools






### 4. Parallel structure diagram




#### ① One ES51.2-400BS product



#### ② Two ES51.2-400BS products



③ More than Two ES51.2-400BS products




Note: 1. When the battery pack is used in parallel, the BMS automatic coding can encode the host to wake up the slave, and the slave can automatically wake up after the host wakes up.

2. There are strict sequence requirements for battery power-on, connect PACK in order from low to high, all connecting wires can only be loaded or charger after installation, and need to be charged or activated by pressing a button after powering on. When dismantling, unplug the charger or load first, and disassemble the PACK from the height to the bottom in turn.

4.1 Recommended setting data of inverter:

| Battery model             | LiFePO <sub>4</sub> /Lithium battery |
|---------------------------|--------------------------------------|
| Model                     | ES51.2-400BS                         |
| Discharge cut-off voltage | 50                                   |
| Over discharge recovery   | 51                                   |
| Normal charging voltage   | 58                                   |
| Surge charging voltage    | 60                                   |
| Overvoltage protection    | 58.4                                 |
| Overvoltage recovery      | 56                                   |
| Discharge cut-off SOC     | 10%                                  |

④ Batteries are connected in communication



## 5. LED instructions



Table1 LED working status indication

| state     | normal/warning/protect  | RUN           | ALM           | Battery indicator LED  |               |               |               | illustrate  |
|-----------|---|---------------|---------------|--|---------------|---------------|---------------|---|
|           |   | ●             | ●             | ●  | ●             | ●             | ●             |   |
| shutdown  | hibernate   | extinguish    | extinguish    | extinguish   | extinguish    | extinguish    | extinguish    | annihilate  |
| Standby   | normal  | flash 1       | extinguish    | According to the battery indicator   |               |               |               | standby mode  |
|           | alert   | flash 1       | flash 3       |  |               |               |               | Module low voltage  |
| Charge    | normal  | Always bright | extinguish    | According to the battery indicator<br>(battery indication maximum LED flashes 2) |               |               |               | Maximum battery LED flashes Move (flashing 2), overcharge warning ALM does not flash during alarm |
|           | alert   | Always bright | flash 3       |  |               |               |               |   |
|           | Overcharge protection   | Always bright | extinguish    | Always bright  | Always bright | Always bright | Always bright | If there is no utility power, indicate Light goes to standby                                      |
|           | temperature, overcurrent, Failsafe                                    | extinguish    | Always bright | extinguish   | extinguish    | extinguish    | extinguish    | stop charging   |
| discharge | normal  | flash 3       | extinguish    | According to the battery indicator   |               |               |               | stop charging   |
|           | alert   | flash 3       | flash 3       |  |               |               |               |   |
|           | Undervoltage protection   | extinguish    | extinguish    | extinguish   | extinguish    | extinguish    | extinguish    | stop charging   |
|           | temperature, overcurrent, short circuit, Reverse connection, failsafe | extinguish    | Always bright | extinguish   | extinguish    | extinguish    | extinguish    | stop charging   |
| invalid   |   | extinguish    | Always bright | extinguish   | extinguish    | extinguish    | extinguish    | Stop charging and discharging   |

Table2 Description of capacity indication

| state              | Charge   |            |            |            | discharge       |            |            |          |
|--------------------|----------|------------|------------|------------|-----------------|------------|------------|----------|
| capacity indicator | L4 ●     | L3 ●       | L2 ●       | L1 ●       | L4 ●            | L3 ●       | L2 ●       | L1 ●     |
| Battery (%)        | 0~25%    | extinguish | extinguish | extinguish | extinguish      | extinguish | extinguish | constant |
|                    | 25~50%   | extinguish | flash 2    | flash 2    | constant        | extinguish | extinguish | constant |
|                    | 50~75%   | flash 2    | flash 2    | constant   | constant        | extinguish | constant   | constant |
|                    | 75~100%  | flash 2    | constant   | constant   | constant        | constant   | constant   | constant |
| Running lights ●   | constant |            |            |            | Blink (blink 3) |            |            |          |

Table 3 LED flashing description

| flashing method | Bright | extinguish |
|-----------------|--------|------------|
| flash 1         | 0.25S  | 3.75S      |
| flash 2         | 0.5S   | 0.5S       |
| flash 3         | 0.5S   | 1.5S       |

Remarks: The LED indicator alarm can be enabled or disabled through the host computer, and the factory default is enabled.

### ◆ Button description and hibernation

#### 1. Button description

- (1) Press the button switch for 1~2s, and the PACK will be powered on; When paralleling, the boot interval between the two PACKs should be less than 30s;
- (2) Press the button switch for more than 5s, and the PACK will be powered off; When paralleling, you only need to press one PACK button switch for more than 5s, and the rest will be turned on normally;
- (3) After the voltage under-voltage protection and under-voltage protection are powered off, press 5 times continuously within 10s to force activation; When paralleling, only one PACK needs to be operated, and the rest are also activated normally

#### 2. Dormancy

When any of the following conditions are met, the system enters low-power mode:

- (1) The single or overall over-discharge protection has not been lifted within 30s.
- (2) Press the button (3~6s) and release the button.
- (3) The lowest cell voltage is lower than the sleep voltage, and the duration reaches the sleep delay time (while satisfying no communication, no protection, no equalization, and no current).
- (4) Standby time is more than 24 hours (no communication, no charge and discharge, no mains).
- (5) Force shutdown through host computer software.

Before going to sleep, make sure that the input is not connected to an external voltage, otherwise you will not be able to enter the low-power mode.

## 6.BMS communication settings

### 6.1 BMS communication and setting

When the load (such as inverter) needs to communicate with the battery, in order to establish normal communication with the load, BMS needs to set the following settings for each brand. The RS485 communication protocols of inverters are different, but there are several RS485 communication protocols inside the inverter to match the battery. When using, you can directly select the communication protocol code in the inverter for matching. If you have other problems, please consult the supplier.


Battery BMS interface pin foot definition as shown in the following figure

When the battery is used in parallel, the BMS can distinguish the PACK through automatic coding, and the definition of the master-slave address refers to the "Communication Address Selection Description";

The "RS485/CAN" battery pack can communicate with inverter through this interface;

"RS485/RS485" is used in the battery pack for parallel use and monitoring software, and the master pack is connected to the slave through this interface Pack to communicate;

#### External interfaces




RS485

RS485

The battery communication interface adopts 8P8C RJ45 socket.

| RS485 |            | PRS485 |            |
|-------|------------|--------|------------|
| PIN   | Definition | PIN    | Definition |
| 1、 8  | RS485-B    | 1、 8   | RS485-B    |
| 2、 7  | RS485-A    | 2、 7   | RS485-A    |
|       |            |        |            |
|       |            |        |            |

#### Internal interfaces



RS485

CAN

The battery communication interface adopts 8P8C RJ45 socket.

| RS485 |            | CAN |            |
|-------|------------|-----|------------|
| PIN   | Definition | PIN | Definition |
| 1、 8  | RS485-A1   | 4   | CAN-L      |
| 2、 7  | RS485-B1   | 5   | CAN-H      |
|       |            |     |            |
|       |            |     |            |

### 6.2 Communication Instructions

#### 6.2.1 CAN Communication

CAN communication, baud rate 500K.

#### 6.2.2 RS485 communication

With RS485 interface, you can view PACK information, the default baud rate is 9600bps, if you need to communicate with the monitoring device through RS485, the monitoring device is the host, and the data is polled according to the address.

#### 6.2.3 Features

- (1) It has 16 channels of single voltage, overall voltage detection, overcharge, overdischarge alarm and protection functions. The quiescent voltage sampling accuracy can reach  $\leq 10\text{mV}$  at room temperature.
- (2) It has the functions of charging and discharging current detection, charging and discharging overcurrent alarm and protection. The charging current is displayed as positive, the discharge current is displayed as negative, and the current sampling accuracy can reach  $\leq 2\%$  @FS at room temperature. Reserved charge and discharge current detection, charge and discharge overcurrent alarm and protection functions. The charging current is displayed as positive, the discharge current is displayed as negative, and the current sampling accuracy can reach  $\leq 2\%$  @FS at room temperature.
- (3) It has 4 cell temperature detection, cell high and low temperature alarm and protection functions. The temperature sampling accuracy can reach  $\leq 2^\circ\text{C}$  at room temperature.
- (4) It has the function of short circuit protection.
- (5) It has a charge equalization function.
- (6) Cell capacity estimation is supported. The full charge capacity, current capacity, and design capacity of the battery pack can be set by the host computer, and the capacity can be automatically updated after a complete charge and discharge cycle.
- (7) Support the software control function of the host computer, and the protection parameters such as overcharge, overdischarge, charge and discharge overcurrent, overtemperature, undertemperature, capacity, sleep, balance, and other parameters can be easily set through the host computer software.
- (8) It has RS485, CAN communication interface.
- (9) It has a variety of sleep and wake-up methods.
- (10) Supports integrated 10A charging current limit.
- (11) It has the functions of reset switch, automatic coding and so on.
- (12) It has LCD interface (optional), charging current limit, buzzer, LED and other functions.
- (13) Online upgrades are supported.

**Note: The battery default protocol is Pylon.**

### 6.3 Inverter Compatibility List



| Inverter brand |                 | Model  | Battery Protocol Selection | Battery Modules |
|----------------|-----------------|--------|----------------------------|-----------------|
|                | Growatt         | LV ALL | Pylon                      | 15              |
|                | SRNE            | LV ALL | Pylon                      | 15              |
|                | Voltronic power | LV ALL | Pylon                      | 15              |
|                | Goodwe          | LV ALL | Pylon                      | 15              |
|                | Deye            | LV ALL | Pylon                      | 15              |
|                | Luxpower        | LV ALL | Pylon                      | 15              |
|                | Megarevo        | LV ALL | Pylon                      | 15              |
|                | SAKO            | LV ALL | Pylon                      | 15              |
|                | Sorotec         | LV ALL | Pylon                      | 15              |
|                | SMK Solar       | LV ALL | Pylon                      | 15              |
|                | Inhenergy       | LV ALL | Pylon                      | 15              |
|                | MUST            | LV ALL | Pylon                      | 15              |
|                | SUNGROW         | LV ALL | Pylon                      | 15              |
|                | Afore           | LV ALL | Pylon                      | 15              |
|                | Solis           | LV ALL | Pylon                      | 15              |
|                | Felicity        | LV ALL | Pylon                      | 15              |
|                | Frecon          | LV ALL | Pylon                      | 15              |

### 6.4 Low Voltage Battery to inverter CAN Terminal Pin Out



| LOW VOLTAGE INVERTER CAN /BMS |              |                        |                              |                                |
|-------------------------------|--------------|------------------------|------------------------------|--------------------------------|
| RJ45                          | CAN TERMINAL | Inverter Terminal Type | Inverter SIDE ( PIN Number ) | Battery SIDE RJ45 (PIN Number) |
| Goodwe                        | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Deye                          | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Luxpower                      | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 3                            | 5                              |
| Megarevo                      | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Sorotec                       | CAN- H       | RJ45                   | 3                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Inhenergy                     | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| MUST                          | CAN- H       | RJ45                   | 6                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| SUNGROW                       | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Afore                         | CAN- H       | RJ45                   | 4                            | 4                              |
|                               | CAN- L       |                        | 5                            | 5                              |
| Felicity                      | CANL1        | RJ45                   | 7                            | 5                              |
|                               | CANH1        |                        | 8                            | 4                              |

## 6.5 Low Voltage Battery to inverter RS485 Terminal Pin Out



| LOW VOLTAGE INVERTER RS485  |                |                        |                              |                                |
|---|----------------|------------------------|------------------------------|--------------------------------|
| <br>RJ45 | RS485 TERMINAL | Inverter Terminal Type | Inverter SIDE ( PIN Number ) | Battery SIDE RJ45 (PIN Number) |
| Growatt   | RS485-B        | RJ45                   | 1                            | 1, 8                           |
|   | RS485-A        |                        | 2                            | 2, 7                           |
| SRNE  | RS485-B        | RJ45                   | 8                            | 1, 8                           |
|   | RS485-A        |                        | 7                            | 2, 7                           |
| Voltronic power   | RS485-B        | RJ45                   | 3                            | 1, 8                           |
|   | RS485-A        |                        | 5                            | 2, 7                           |
| SAKO  | RS485-B        | RJ45                   | 3                            | 1, 8                           |
|   | RS485-A        |                        | 5                            | 2, 7                           |
| Frecon  | RS485-B        | RJ45                   | 1                            | 1, 8                           |
|   | RS485-A        |                        | 2                            | 2, 7                           |
| SMK Solar   | RS485-B        | RJ45                   | 1                            | 1, 8                           |
|   | RS485-A        |                        | 2                            | 2, 7                           |
| Solis   | RS485-B        | RJ45                   | 1                            | 1, 8                           |
|   | RS485-A        |                        | 2                            | 2, 7                           |

### INFORMATION

Regarding the communication between the battery and the inverter, the battery side needs to maintain the original configuration, but inverters of different brands and models may have different communication pins. If in doubt, refer to the inverter manual.

## 7. Technical parameter list



|                                     |  |
|-------------------------------------|--|
| Product number                      | ES51.2-400BS                               |
| Array Mode                          | 16S  |
| Nominal Capacity (Ah)               | 400  |
| Nominal Energy (KWh)                | ≥20  |
| Nominal Voltage (V)                 | 51.2                                       |
| Charge Voltage (V)                  | 58.4                                       |
| Discharge Cut-off Voltage (V)       | 42   |
| Standard Charging Current (A)       | 20   |
| Max.Continuous Charging Current (A) | 100  |
| Max.Continuous discharging Current  | 100  |
| Cycle Life                          | 6000 Cycles @80% DOD @25°C @0.2C/0.2C      |
| Communication Mode                  | RS485/CAN                                  |
| Operating Temp                      | Charging: 0~60°C; Discharging: -10°C~60°C  |
| Size (L×W×H) mm                     | cabinet: 600×600×1000; module: 515×493×175 |
| Weight (Kg)                         | cabinet: ~30; module:~44                   |
| Gross weight (Kg)                   | cabinet: ~32; module:~48                   |

Note: The dimensions in the data sheet are the product appearance dimensions. If any change for the products, will adjusted by the manufacture.

## 8. Maintenance and conservation



| Item | Problem description   | Possible causes   | Solution   |
|------|---|---|--|
| 1    | The battery cannot be turned on normally, and there is no response when pressing the button.  | 1. The button is damaged or the button cable is disconnected;<br>2. BMS damaged;<br>3. The battery is seriously over-discharged.  | 1. Check whether the button is normal;<br>2. Check whether the voltage of the battery pack is normal;<br>3. If the voltage of the battery pack is too low, you need to use a constant current power supply or a lithium battery charger to charge the battery until the low voltage protection is released.  |
| 2    | The BMS immediately enters the protection state after pressing the switch.  | 1. Battery pack voltage is abnormal;<br>2. Abnormal temperature;<br>3. External load mismatch.  | 1. Check whether the voltage of the battery pack itself is consistent;<br>2. Check whether the BMS voltage collection is abnormal;<br>3. Confirm whether the ambient temperature exceeds the BMS temperature preset value and whether the temperature probe is damaged;<br>4. Determine whether the load power and voltage match the battery.  |
| 3    | The communication fault occurs when the load is inverter  | 1. Communication line connection error (improper pin connection or poor contact);<br>2. Does not match the inverter communication protocol;<br>3. Communication mode do not match;<br>4. Correspondence address error;<br>5. Signal interference. | 1. Check whether each pin of the communication line is broken;<br>2. Check whether the corresponding pins are connected correctly;<br>3. Check whether the contact part of the communication cable connection terminal is oxidized;<br>4. Confirm whether the inverter selects the matching protocol;<br>5. Confirm whether the correct communication method is selected, such as CAN and RS485 or other communication methods;<br>6. Confirm whether the inverter needs to select a communication address, and confirm whether the battery communication address is correct;<br>7. Confirm whether there are high-frequency interference sources in the battery usage scenario. |
| 4    | The output is suddenly disconnected during use  | 1. The battery voltage is too low, triggering BMS protection;<br>2. BMS protection caused by excessive load power or short circuit at the output end.   | 1. Check whether the battery voltage is within the normal range. If the voltage is low, charge the battery;<br>2. Adjust the load power to match; short circuit: disconnect the load or restart the battery.   |
| 5    | SOC does not match actual value   | 1. SOC cumulative error during charging and discharging;<br>2. SOC is not calibrated;<br>3. The internal battery parameters of BMS have changed.  | 1. Calibrate the SOC, discharge to battery protection and then charge to 100% of the battery to complete the calibration;<br>2. After the parameters related to the internal battery capacity of the BMS change, the SOC needs to be re-estimated and a power calibration needs to be performed.   |
| 6    | In order to protect your rights and interests, after you purchase our products, if you encounter problems with the installation and use of the product, you can contact the supplier, and we will provide you with after-sales service as soon as possible. |   |  |

In order to maintain the best and long-term performance, the following items are recommended to be inspected twice a year.

1. Confirm that the surrounding air flow will not be blocked, and remove any dirt and debris on the cooling hole.
2. Check all exposed wires, shabby and damage, please replace or repair them if necessary.
3. If it is not used for a long time, it is recommended to charge it every three months.



**Danger of electric shock! Make sure that the power supply has been disconnected during the above operations, and then carry out corresponding inspection and operation.**

## Warranty Card and Warranty Condition



### Product Information

Battery Model

Serial No.

Purchase Date

Dealer/Installer

Commissioning Date

Seal of Dealer/Installer

### End User Information

Customer Name

Phone Number

Email

Detailed Address

## 1. Purpose

The primary purpose of this warranty letter is to clearly define the matters related to warranty policy of products.

## 2. Warranty Condition

### 2-1. Warranty Period

Eastman promises the warranty period is 5 years (please refer to the sales contract for the specific warranty terms), and the warranty period is calculated from the date of receipt .

### 2-2. Limitation of Warranty scope

Eastman liability under this Warranty Letter shall be limited to replacement, repair, refund and compensation. Replaced or repaired Products shall be warranted for the remainder of the original Term of Performance Warranty. In any event, the replacement shall not justify the renewal of the Term of Performance Warranty.

### 2-3. Exclusion of Warranty

Damage to the Products resulting from any of following activities is NOT covered by this Limited Warranty:

Improper transportation, storage, installation or wiring by Buyer. Modification, alteration, disassembly, repair or replace by someone other than a personnel certified by Eastman. Noncompliance with Eastman's official installation manual. External influences including unusual physical or electrical stress (power failure surges, inrush current, lightning, flood, fire, accidental breakage, etc.) Use of an incompatible inverter, rectifier or PCS.

### 2-4. Warranty Claim

In general, serial number(S/N) must be provided in order to claim warranty. Please store the original purchasing invoice/ installation documents or receipts carefully. Customers need to present it for warranty claim if required. Buyer shall contact supplier directly for any warranty claims in order to avoid additional problems in the products.

Note: Products are unavailable to protect itself from the self-discharge in condition of shut down mode. So please charge the batteries to 80% every 3-6 months.

## 3. Performance Warranty (Standard)

Eastman warrants and represents that the Product retains at least Cycle life of 6000 Times @80% DOD, 25°C. 0.2C charge and discharge with 80% DOD. Standard for 5year warranty with 6000 cycle @80% DOD, 25°C, 0.2C. The ambient temperature during the operation of the Products shall not fall below 0°C or exceed 60°C

Capacity measurement condition

Ambient temperature: 77 ~ 86°F (25 ~ 30°C)

Initial battery temperature from BMS: 77 ~ 86°F (25 ~ 30°C)

Charging/discharging method - 0.2C charge & discharge with 80% DOD

Current and voltage measurement at battery DC side

## 4. Out of Warranty Policy

Products damage which is not caused by seller, buyer shall provide charged service, including all the expenses of such as material cost, labor cost, warehouse cost, transportation cost, customs duties, analysis cost, management cost, corporate profits, disposal expense (If necessary) and so on.

## 5. Warranty Guarantee

For the goods that have passed the acceptance inspection, if the relevant documents are not complete, the brand does not conform to the requirements and quality problems before your company puts them into use, Eastman promises to return the goods unconditionally and supplies qualified goods within the time specified by your company.

When the products had issuer after installation,

A. Please contact us immediately, our sales and engineer will offer you the accessories for free and technical support to help you solve the issue.

B. If the battery is confirmed non repairable even after repair within warranty, we will replace one by one for you within 1 month.

## 6. Claim Payment Policy

Claims under this Warranty must be made by notifying the supplier from whom the Product was purchased.



[www.eastmanworld.com](http://www.eastmanworld.com)  
[marketing@eastmanworld.com](mailto:marketing@eastmanworld.com)

**AMPS MIDDLE EAST FZ LLC**

#703, 7<sup>TH</sup> Floor, Deira Twin Tower,  
Baniyas Square, Deira, Dubai (UAE)

**EASTMAN AUTO & POWER LTD.**

ASF Towers, 249, Udyog Vihar Phase-4, Gurugram,  
Haryana-122016, India

**EASTMAN NEW ENERGY PRIVATE LIMITED**

Plot No 264, Sector-7, IMT Manesar, District - Gurugram  
Haryana-122050, India

Follow us on »  @eastman\_world  @EastmanWorld  @EastmanWorld